

REAR BODY BRACE

Golf 7 // Golf 7.5







FITTING INSTRUCTIONS







WHAT'S IN THE KIT?

- 1 x Top Brace Bar
- 2 x Lower Brace Bar
- 2 x Luggage Brace Mount
- 2 x Upper Centre Mount
- 2 x Upper Mount (Lower)
- 2 x Upper Mount (Top)
- 6 x M4 (16mm) Cap Head Screw
- 4 x M4 (14mm) Cap Head Screw
- 4 x M4 (18mm) Countersunk Screw
- 2 x M8 (26mm) Countersunk Screw
- 4 x M8 (28mm) Countersunk Screw
- 1 x M6 Tensioner

REQUIRED TOOLS AND PARTS

-  2.5 mm Allen
-  3 mm Allen
-  5 mm Allen
-  10 mm Spanner
-  M8 Spline
-  Screwdriver/Trim Removal Tool

FITTING NOTES

-  Preassemble top bar with 2 x Upper Centre Mount and 2 x Upper Mount (Lower) before offering up to vehicle.
-  Tensioner has a left-hand and right-hand thread, check orientation before assembling in Upper Centre Mount.
-  Before fully tightening brace in place, ensure rear seats click securely into place correctly.
-  Use centre tensioner to pretension the two-lower brace bars.



FITTING INSTRUCTIONS

VWR85G700



RACING LINE

Step 1:

Luggage brace mount fitment – Using a screwdriver/removal tool, open the cover on the OEM luggage net mount. Once open remove using an M8 spline. Replace with luggage brace mount, using 2 x M8 countersunk screw. (Ensure orientation is correct, Countersunk hole should be facing the rear of the vehicle)



Step 2:

Installation of top brace bar – Preassemble 2 x upper centre mount and 2 x upper mount (Lower) on upper carbon brace bar. Offer up to the vehicle and loosely bolt upper mount (Top) onto upper mount (Lower) using 6 x M4 (16mm) cap head screw.

Step 3:

Installation of lower brace bars – Loosely bolt both lower brace bars into the luggage brace mount using 2 x M8 (28mm) countersunk screw. Next bolt one lower brace into the upper centre mount. Using the tensioner line up the remaining brace and bolt into place using 2 x M8 (28mm) countersunk screw.



Step 4:

Final fitment – Now all components are loosely installed, the final step is to tighten everything into place. Start with upper mount (ensure rear seats click into place fully), then turn centre tensioner until both lower braces are held firmly. Now tighten the remaining screws until all components are held solidly in place.

